

Left Electrical Lead




May 18, 2007

Adding Supplemental Insulation



Extra Layers of Armaflex



May 18, 2007


View of center tri-port tack welds



View of copper bar male thread



Work on the Solenoid Leads



May 23, 2007